



GF502 双轴摆动 用户手册

GF502 Biaxial swing User Manual

Empower 嘉强

Hotline: 400-670-1510

Email: sales@empower.cn

Add: 上海市 松江区东宝路 8 号



	V2.0
	2020/05/18

V1.0	2020/05/18					

GF502

, !

1		3
1.1		3
2	-	4
2.1		4
2.2		6
3		7
4		8

1

GF502

GF502 ,

1.1


-
-
-
-
-
-

	A ± 50 ° B ± 45 °
	A 64r/min B 64r/min
	137rad/s ²
	± 0.02mm
	± 0.01mm
BM111	16KG

1 GF502 A 21 B 22 A

1 15 23 ,

- (1) A
- (2) B :
- (3) A
- (4)
- (5)




1 GF502

P120AB3000,


2 -

2.1

GF502	AB	A	B	A
	2			
	3			




2 A






5 GF502

P120AB3000,



5 GF502



6 GF502 A B

4

4.1

A B

4.2

RTCP